

Foot Peg Fitting Guide (MPW-ADV-007)

- 1, Thoroughly clean the area of the Foot Pegs are located.
- 2, Firstly remove the Split Pin by bending the 2 halves together again, and then sliding it out of the main Pivot Pin.
- 3, Next remove the Washer sat behind the Split Pin.
- 4, Now you can withdraw the Pivot Pin making note of the Return Springs orientation. The original Foot Peg will now come away freely from the bike.
- 5, While you have the components apart now is a good time to clean them again and apply some fresh grease.
- 6, Now start inserting the Pivot Pin, then offer up the new Foot Peg with the Return Spring in position. Once the Pivot Pin is fully home, you can slide the Washer back on and reinstall the Split Pin ensuring the tails are bent back round the Pivot Pin.
- 7, Repeat Steps 2-6 for the other side of the bike.

That is, it the install is complete, and you should go for a well-deserved test ride.