

## Handguard Fitting Instructions (MPW-ADV-015)

Note, Motorcycle manufacturers do not produce a bike with handguards in mind. Be aware that cables may need re-routing and any windscreen may need adjusting to clear the handguards.

1, First step is to remove the existing Bar Ends and place somewhere safe as you will not be re-using these.

2, The new Bar Ends supplied in the kit are designed to be a direct fit to existing Bars.

3, Now you can fit the new Bar Ends (loosely). The Bolt should pass through the End Cap, then the Main Support Bar, lastly the Spacer Bush. As you screw the Bolt into the end of the Handlebars notice the slot cut into the End Cap which will seat the Main Support Bar.

4, Next fit the inner most Clamp to the Handlebars. To do this simply fit the bolt on clamps noticing that they will attach to the Main Support Bar in an underslung fashion. Don't fully tighten the Bolts but nip them up just enough to hold the Handguard in its rough position.

5, Next select the Plastic Guards for each side and bolt them to the Main Support Bars with bolts passing right through to have Nuts attached with washers on the inside face. These can also be Fully tightened at this point.

6, With Step 5 done you can now adjust the Handguard up or down to suite your hand and lever positions. Once this is done you can fully tighten All the remaining bolts.

The install is now complete, and you can take a well-deserved test ride.