

Tank Pad Fitting Guide (MPW-ADV-022)

1, Before you begin, thoroughly clean and de-grease the area around the Fuel tank.

2, Next you will see there are 3 Tank Pads supplied. Take the single smallest Tank Pad and offer it up to the Tank. If it helps add some masking tape directly above and/or below its desired location and mark centre lines to ensure the Tank Pad is mounted centrally and square.

Once you are happy with-it s final location carefully peel the backing tape off then simply stick the Tank Pad in place.

Its wise to use a Heat Gun and give the Tank Pad a gentle warm up to help the glue really take hold.

3, Now take the 2 Side Tank Pads. Offer them up to the Tank and you will see one per side matches the contours of the Tank. With this in mind, using the same methods as Step 2 add any masking tape that helps you properly align the Tank Pads evenly and square.

Again once you are happy peel off the backing tape and carefully stick the Tank Pad in place, using the Heat Gun to help activate the Glue.

4, Repeat Step 3 for the other side of the bike.

That is, it the install is complete, and you should go for a well-deserved test ride.