

## GPS Mounting Bracket Fitting Guide (MPW-ADV-060)

1, Before you begin, thoroughly clean the area around the main Handlebar Clamps.

2, Loosen and Replace 1 by 1 the four Clamping Bolts with the NEW special 2 Stage Bolts, which contain the extra threaded hole at the Top.

3, With the 4 new Bolts fully installed and tightened you can now mount the 2 Triangular Mounting Brackets using the 4 smaller matching Bolts and Washers by screwing them into the special 2 Stage Bolts already installed. Note you can mount the Brackets so the 12mm Bar is closer to you or further away, but also note the Brackets must curve outwards to accommodate the 12mm Cross Bar.

Do not fully tighten these 4 Bolts just yet.

4, Using the remaining 2 Bolts pass them through Mounting Brackets and screw them into the 12mm Cross Bar. It would be wise to add a little thread lock to these 2 Bolts.

5, You can now Tighten ALL of the 6 smaller Bolts.

6, The mount is now ready accept your GPS or other accessories.

That is, if the install is complete, and you should go for a well-deserved test ride.