

## Handguard Protectors Fitting Instructions (MPW-ADV-061)

1, Remove the Bolt holding the fitted Handguards at the Bar End. Remove any Bar End Spacer also.

2, Pass the new supplied Bolt, pass it through the Protector, then through the Stepped Spacer, then through the Handguard, then the new black Bar End where you finally screw on the expanding collet. Tighten the collet lightly but not so it starts to expand.

3, Insert the above into the end of the Handlebar, but don't fully tighten yet.

4, Next assemble the Inner Handlebar Clamps around the Handlebars and secure them to Protector also with the supplied Nuts and Bolts.

5, Now take some time positioning the Handguards and Protector Bars so they are in your desired position. You can fully tighten ALL the fixings.

6, Double check no cables or levers are caught or snagged in the install.

The Install is complete, you can now take a well-deserved test ride.