

TFT Glare Shield Fitting Guide (MPW-ADV-080)

1, Before you begin, thoroughly clean the Display and its Surround.

2, Next take the Anti-Glare Shield and offer it up to the Screen. You will see it only fits properly in 1 orientation.

3, Now hook the Top 2 Corner Clips/Tabs over the Screens Top Corners and push home.

4, Next manoeuvre the Single Lower Central Clip/Tab over the Screen and as above push it fully home.

5, With All Clips/Tabs fully pushed on the Glare Shield is now locked in place securely.

That is, it the install is complete, and you should go for a well-deserved test ride.