

## Handguard Protectors Fitting Instructions (MPW-ADV-099)

1, Remove the Bolt holding the fitted right hand Handguard at the Bar End. Place the Bolt to one side as you will not be re-using.

2, Regarding the inner mounting. The kit comes supplied with 2 sizes of Bolts and Spacers, so you can mount the protectors either with or without the BMW Sta-Nav system.

3, So with Step 2 understood loosen and remove the appropriate 2 Bolts.

4, Now offer up the Protectors. You will notice they will only fit in one orientation. Firstly, using the largest supplied Bolt insert it through the Outer single mounting hole, then through the existing Handguard and screw it into the Handlebars. Don't fully tighten at this point.

5, Next take the 2 appropriate Bolts/Washers/Spacers required to attach the Protector to the Handlebar Clamp area and screw them in. You can fully tighten these Bolts at this stage.

6, With Step 5 complete you can fully tighten the single Large Bolt fitted in Step 4.

7, Lastly double check all Cables and existing equipment is not snagged or hampered by the above install.

The Install is complete, you can now take a well-deserved test ride.

