

Cross Bar Brace Fitting Guide (MPW-ADV-101)

- 1, Before installing the Brace ensure the handlebars are thoroughly clean and no cables or equipment will be impacted by the addition of the Brace.
- 2, Firstly loosen and remove the clamping bolts from the Brace.
- 3, Then wrap the 2 Brace Clamps around the Handlebars and screw in the Outer Bolts to help keep the Clamps in place.
- 4, Now you can offer up the main Bar and slot it into the 2 fixing points on the Clamps.
- 5, You will find that the Clamps need to be slid either up or down the Handlebars, so the fixing points match the Bars length. Take care not to scratch any paint doing this.
- 6, Once you are happy with all the fixings double check you have the assembly horizontal to the Handlebars and then fully tighten the Cross Brace

That is, it the install is complete, and you should go for a well-deserved test ride.