

Heel Guards Fitting Guide (MPW-SVG-0105-03)

1, Thoroughly clean the area of the Heel Guards are located.

2, Next remove the 2 Bolts currently holding the Factory Heel Guards in position and remove the Heel Guard.

3, Now offer up the new Heel Guards ensuring they are in the correct orientation.

4, Insert the 2 Bolts and once both are fitted fully tighten to factory settings.

5, Repeat Steps 2-4 for the other side of the bike.

That is, it the install is complete, and you should go for a well-deserved test ride.