

Screen Installation Guide (MPW-SVG-0113-05)

Before you begin thoroughly clean your Motorcycles Windshield.

1, Firstly assemble the Screen Brace Bar with the Screen, using the supplied Top Hat Bushes, and 4 bolts with nuts and washers.

2, Insert all Top Hat Bushes from the outside into the already installed rubber cushions in the Screen.

3, Then loosely install the 4 Bolts/Washers and Nuts into the Screen and Brace Bar.

4, Once all 4 are fitted fully tighten. Be careful not to over tighten, keeping an eye on the Rubber Cushions deforming.

5, Next remove the original Screen from the bike. The Screen kit comes supplied with replacement expanding sunken Nuts. So with the Screen removed you now have access to exchange these nuts for the new ones.

6, Now offer up the Screen to the bike lining up the 4 fixing holes with the bikes mounting points.

7, You can now insert the Top Hat Bushes and remaining Screws and Washers loosely. Once all 4 fixings are in you can fully tighten, again taking care not to over tighten.

8, Finally give the Screen a clean to remove any dirt or oil applied during fitment.

Lastly take your bike for a much-deserved test ride.