

## Front Calliper Guard Installation Guide (MPW-SVG-0114-03)

- 1, Thoroughly clean the area around the Front Brake Callipers.
  
- 2, Firstly bolt the smaller ABS sensor guard to the LH Fork Leg Base using the supplied Bolt.
  
- 3, Next offer up both Calliper Guards to the LH Calliper to be certain which one you require.
  
- 4, Now loosen and remove the 2 Rear facing bolts that match the fixing locations on the Guard.
  
- 5, You can now pass the 2 Bolts through the Calliper Guards fixing points and screw back into the Calliper.
  
- 6, Fully tighten once both are into factory specifications.
  
- 7, Repeat Steps 3-6 for the RH side Calliper.
  
- 8, Lastly rotate the wheel to check nothing is rubbing or loose, and also check the action of the Front Brake Lever.

Now go for a well-deserved ride.