

Rear Calliper Guard Installation Guide (MPW-SVG-0118-03)

1, Thoroughly clean the area around the Rear Brake Calliper.

2, Next offer up the Calliper Guard to the LH Calliper to be clear about the mounting position.

3, Now loosen and remove the 2 Bolts that match the fixing locations on the Guard.

4, You can now pass the 2 supplied Bolts through the Calliper Guards fixing points, then the supplied Spacers and then into Calliper.

6, Fully tighten once both are in, to factory specifications.

7, Lastly rotate the wheel to check nothing is rubbing or loose, and also check the action of the Rear Brake Pedal.

Now go for a well-deserved ride.