

Frame Guards Fitting Instructions (MPW-SVG-0124)

- 1, Thoroughly clean the bikes Frame around the area the Guards are to be fitted.
- 2, Working on the LH side first. Use the Guard that has the extra 3rd circular shape in the moulding.
- 3, Offer the Guard up to the Frame directly above the front foot pegs. You will see the Guard can only fit in one orientation.
- 4, Next take 3 of the supplied cable ties and wrap them round the Guard and Frame using the Slots engineered into the Guards to locate the cable ties.
- 5, With all 3 cable ties in location pulled fully tight, carefully cut off the excess cable tie and then rotate them so the joint part is at the rear of the Frame out of site.
- 6, Now screw the central Bolt fixing in securely.
- 7, Repeat Steps 2-6 for the RH side of the bike.

Now go for a well-deserved test ride.