

## Grill Guards Fitting Instructions (MPW-SVG-0129-03)

1, Thoroughly clean the area around the 2 intakes on the bikes panels.

2, Next take the Guards and offer them up to the Bike so you can ascertain which one goes on which side and in which orientation.

3, Now take one side's Grill, loosen and remove the Intake panels retaining screw and place to one side.

4, Then use the supplied Screw and Washer to fasten the Grill in place inside the Air intake panel.

5, Repeat Steps 2-4 for the other side of the bike.

Now go for a well-deserved test ride.