

Radiator Guard Fitting Instructions (MPW-SVG-0132-03)

- 1, Firstly thoroughly clean around and including the Radiator prior to fitting.
- 2, Next take the 2 Guards and offer them up to the bike so you are able to check which guard goes on which side and in what orientation.
- 3, Now doing 1 Guard at a time loosen and remove the 2 Bolts required to hold the Guard.
- 4, Then offer the Guard up in position over the Radiator and insert the 2 Bolts.
- 5, Once the Bolts are in and you are happy with how the Guard is seated you can fully tighten the 2 Bolts to factory specifications.
- 6, Repeat Steps 3-5 for the 2nd Guard.
- 7, Lastly check everything is fixed firmly in place and no cables or pipes are pinched or trapped.

The install is complete and you can now go for a well deserved test ride.