

## Replacement Rubbers Fitting Guide (MPW-SVG-0134)

1, Thoroughly clean the Foot peg area before installing.

2, The Foot peg Rubbers are designed to be a push/friction fit.

3, Carefully prize out the existing rubbers looking for the 2 tapered rubber catches releasing from the metal work of the Foot peg.

4, Again clean inside the now exposed Foot peg metal work.

5, Now apply a small amount of lubricant to the rubber catches on the base of the new Rubbers.

6, Manipulate the Rubber so the 2 catches both cleanly pass through the Foot peg and check they are firmly in place.

That is, if the install is complete, and you should go for a well-deserved test ride.