

Side Stand Shoe Installation Guide (MPW-SVG-0136-02)

Before you begin, clean the side stand thoroughly. If you have a centre stand you should place the bike on it for this job. If you do not have a centre stand it might be advisable to have a second pair of hands to help balance the bike.

- 1, With the side stand down, offer the Shoe up to the side stands stock foot. You will now see the Shoe only fits in one orientation. Remember this.
- 2, Next loosen and remove the fixing bolts from the top face of the Shoe.
- 3, Now place the bikes stock foot into the recess in the Shoe.
- 4, With the Shoe base positioned you now need to offer up the clamping bolts and countersunk washers. Once in position start winding in the fixing bolts.
- 5, Once the bolts are in finger tight, it's wise to tighten them gradually working round each bolt in turn. This way all the bolts will tighten easier, and the Shoe will sit level.
- 6, Once all the bolts are fully tightened and the Shoe is sitting flush with the bottom of the foot, the install is complete.
- 7, You can now test the side stand with the Extension Shoe fitted.
- 8, Lastly go for a well-deserved test ride.