

## Foot Peg Hangers Fitting Guide (MPW-SVG-0149)

- 1, Thoroughly clean the area the Hangers are going to attach.
- 2, If you are replacing existing Hangers start by loosening and removing the 2 fixing bolts holding them to the frame, and then lifting the Hangers clear.
- 3, With the original hanger Removed use the identical new Hanger and simply re-fit this in the location you removed the old one.
- 4, Once both Bolts are in you can fully tighten to factory specifications.
- 5, Repeat steps 2-4 on the other side of the bike.
- 6, If the bike did not have Hangers to remove simply offer up the new Hangers to check for which side fits which. The actual Foot peg should fold up when not in use.

That is it the install is complete, and you should go for a well-deserved test ride.