

## Highway Footpeg's Fitting Guide (MPW-SVG-0162)

- 1, Thoroughly clean the area of the Engine Bars you intend to fasten the Highway Pegs to.
  
- 2, Some disassembly is required of the Highway Peg.
  
- 3, Start by removing the large bolt and nut that runs through the Peg. This will allow the Clamping Section to separate from the Peg section. Also remove the 2 metal bushes the bolt passes through.
  
- 4, Next ensuring the longer support finger is on the outside and pointing towards the front of the bike, fasten the Clamping section to the bikes Engine Bars using the 2 smaller Bolts to tighten down the Clamp from the rear side of the Clamp.
  
- 5, Now slide the Peg section back over the clamping section and line up the holes.
  
- 6, Lastly insert the 2 Bushes, then insert the large Bolt and screw the Nut back on the bottom. The Bolt should be wound flush with Nut for the correct tightness.
  
- 7, The Highway Peg should now fold in and out with some resistance so it remains firm in each position.

That is, if the install is complete, and you should go for a well-deserved test ride.