

## Fender Extender Fitting Guide (MPW-SVG-0166)

1, To ensure you get a well fitted Extender preparation is key. So it is suggested you remove the Fender from the bike to begin with.

2, Start by offering up the “to be” hidden part to the Extender to the Fender. Once you have it positioned by hand where you would like it, use some masking tape or something similar to mark on the Fender the section the 2 parts will overlap.

3, Different Extenders use different screw sizes. So, use the correct sized small drill bit to drill the 3 pilot holes for the supplied self-tapping screws. These 3 holes should be positioned 1 on either side and 1 centrally to maximise rigidity.

4, With the holes drilled and deburred, clean all mating surfaces thoroughly. Offer the 2 parts together again so the holes line up and screw the 3 screws in and fully tighten.

5, Now refit the Fender.

6, One extra step you could take, is to apply some outdoor Silicone Sealant to the mating surfaces or the internal (unseen) joint to help prevent water and debris getting between the 2 parts.

That is, if the install is complete, and you should go for a well-deserved test ride.