

Extension Fitting Instructions (MPW-SVG-0178-01)

- 1, Remove the fitted Handguard. Leave the Handlebar Clamp in place on the handlebars.
- 2, Insert the Extension inside the handguard so it locates snugly and the fixing holes line up.
- 3, Re-fit the handguard.
- 4, Now go for a well-deserved test ride.

Top Tips

- 1, On some occasions you may need to adjust the brake or clutch lever position or re-route cables along the handlebar to avoid clashing with the Handguard.
- 2, As mentioned above its best not to fully tighten any fixings until all of them are in place and the handguard is correctly positioned.
- 3, Remember you can always use the photos on the MPW website for reference with these instructions.