

Screen Extension Installation Guide (MPW-SVG-0195-05)

Before you begin thoroughly clean your Motorcycles Windshield.

- 1, Firstly attach the Screen Mount to the supplied Screen Extension. This is done using the Two grub screws. Note the smaller end with the 2 grub screws close together is used for the above.
- 2, Next loosen the single pivot bolt so you can adjust the angle of the 2 lower mounts that attach to the original bikes Windshield.
- 3, Then loosen the two lower grub screws. You can now offer the Extension up to the Windshield. Look out for the 2 gripper plates on the ends of the grub screws and ensure they stay in place on the screws as these prevent the grub screws from damaging the Windshield.
- 4, Before tightening the above 3 fixings ensure the Extension is mounted centrally and is level. You can now snug these fixing up taking care not to over tighten.
- 5, Now the Extension is properly attached you can loosen the middle linkage bolts to adjust the height and angle of the Extension.
- 6, It is wise to take an Allen key out with you for the first few rides so you can stop and make any small adjustments required.
- 7, Lastly take your bike for a much-deserved test ride.