

Screen Adjuster Fitting Guide (MPW-SVG-0303-03)

1, Carefully remove the Screen from the bike by undoing the 4 Bolts.

2, With Screen removed you now have access to the 4 fixing points. Note these fixing points on the Bike also have an upper and lower position so choose that option now.

3, This will reveal a second smaller Bolt that is threaded into the 25mm Clamping section. Undo this Bolt and the middle section will peel away from the Bottom section.

4, Orientation of the Mounts.

A, The slots run vertically and should be positioned so they are inboard not outboard.

B, The slots have a channel on one side, this should be on the back side.

C, The 2 mounting holes should be at the base when fitted.

5, With the orientation understood attach the 2 Mounts using the 4 Bolts and Washers.

6, Next remove the 4 smaller Bolts, Washers and Nuts from the Slider sections.

7, Now you can offer the screen up to the Slider section. An extra pair of hands will make this task easier. Then pass the Bolts through the thin plastic washers, through the screen and spacers and place a nut back in the rear side channel and screw the Bolt into it. Repeat this for all 4 bolts.

8, Slide the Screen to the desired height and then fully tighten the 4 bolts fitted in Step 7. Note do not over tighten these bolts as it may cause damage to the Screen.

That is, if the install is complete, and you should go for a well-deserved test ride.