

## Frame Slider Crash Protectors Fitting Guide (MPW-SVG-0315-03)

1, The Crash Protectors are designed to fit to the bikes Frame directly behind the Radiator where 2 points of the Frame meet creating a T section.

So, to begin thoroughly clean this area of the bike so as not to possibly damage the paint on the Frame when tightening the Sliders clamps.

2, Now the frame is clean remove the Sliders from the box. You will quickly see by offering them up to the bike they can only go on one side each, and only fit in one orientation.

3, Next undo and remove the 3 Bolts on one of the Sliders. Be careful not to drop the 3 small spacers and backing/clamping Plate.

4, Position the Slider on the frame as mentioned in Step 1 so it bridges the T joint in the Frame behind the Radiator. It is naturally a very snug fit.

5, Now insert 1 of the Bolts, slide one of the Spacers over the end of the bolt, then offer up the Rear Clamping Plate and screw in the Bolt. Do Not fully tighten at this stage.

6, Repeat Step 5 for the remaining 2 Spacers and Bolts.

7, Now All 3 Bolts are in and the Slider is located you can Fully tighten them.

NOTE: If your bike has aftermarket Engine Bars you should check they won't clash/cover the Frame where the Sliders are located.

That is, if the install is complete, and you should go for a well-deserved test ride.