

Helmet Lock Fitting Guide (MPW-SVG-0317)

1, Thoroughly clean the area around the fixing points for Helmet Lock located on the frame directly under seat location.

2, Loosen and remove the 2 existing Screws that hold the rear side panels to the frame..

3, Next pass one of the supplied Bolts through the lower mounting hole of the Lock, then slide one of the supplied Stepped Spacers over the bolt.

4, Now offer this up to the bike ensuring the Stepped Spacer sits correctly and loosely tighten the bolt.

5, Repeat Step 4 for the 2nd Bolt and Spacer.

6, Once both Bolts are in place you can fully tighten the Bolts up.

7, You can now unlock the Clasp using one of the 2 supplied keys to check functionality.

That is, it the install is complete, and you should go for a well-deserved test ride.