

## Foot Peg Fitting Guide (MPW-SVG-0319-02)

1, Thoroughly clean the area of the Foot pegs.

2, Before removing the existing Foot peg check for orientation and angle of the Foot pegs mounting bar, so you select the correct one for each side.

3, Next remove the Foot peg retaining pin and any components remembering their location and orientation.

4, The existing Foot peg should now come free of the mount.

5, Now use this opportunity to thoroughly clean and re-grease all the components. This will help with smooth operation and help prevent corrosion.

6, Next offer up the new Foot peg and line it up, so the holes are all in line.

7, Now re-fit all the components removed in Point 3 above.

8, Repeat ALL the points above for the other side of the bike.

9, Lastly check everything is secure and the hinging action works properly.

That is, if the install is complete, and you should go for a well-deserved test ride.