

Forward Controls Fitting Guide (MPW-SVG-0321-03)

1, As these parts are a direct replacement, we advise the following.

2, Remove and Replace one item at a time, so no mix ups can occur with hardware. Maybe take a few photos for reference too.

3, Take the time to clearly note or lay out each Nut, Bolt, Washer, and Clip carefully to ensure easy re-attachment with the new parts. Sometimes drawing round the items on cardboard and then puncturing holes in it for the bolts to go through in their location helps.

4, Use this time wisely and thoroughly clean any components being re-used and re-grease All moving components.

5, Once you have fully fitted the Kit, ensure all fixings are tightened to factory settings, and check the operation of the Rear Brake and Gear Selector.

That is, if the install is complete, and you should go for a well-deserved test ride.