

Luggage Rack Fitting Instructions (MPW-SVG-0337-03)

1, Thoroughly clean the bikes Rack Mount and Passenger Grab Rails

2, Attach the Backrest to the Luggage Rack using the 3 Bolts and Nuts supplied. You will see the 3 holes line up on both parts and the securing Bolts simply pass through. Fully tighten all 3 at this point.

3, Take the supplied Luggage Rack and turn upside down. Underneath you will see 4 Stainless Steel Allen Bolts with Washers. Loosen and remove these now.

4, Now you can offer up the Luggage Rack to the Rack Mount on the bike. You will see the 4 fixing points on both items line up.

5, Next screw in the 4 Bolts removed in Step 3 loosely, passing them through the Rack Mount into the Luggage Rack from underneath. Once ALL 4 Bolts are screwed in you can fully tighten. Note if doing more Off-Road riding it might be wise to add some Liquid Thread-lock to the Bolts to help them stay securely fastened.

6, The Luggage rack is now Fully fitted. If you now look underneath the Rack you will see 4 Thumbscrews. These are used to loosen the Expansion Sliders. Once loose you can expand the Rack to take larger items. Once at the desired width fully tighten the Thumbscrews again. As with Step 5 Thread-lock might be a wise addition.

7, The rack as covered in Step 6 is adjustable in width to take varying sized luggage. It also has 6 slots for using straps to hold the Luggage in place.

Now go for a well-deserved test ride.

