

Handguard Fitting Instructions (MPW-SVG-0352-03)

- 1, Open the packaging and separate evenly all the components into Left and Right piles.
- 2, Remove the bolt that holds the existing right-hand Bar-End into the handlebars and place the bar end to one side as you will not be re-using this again. Only do one side for now.
- 3, Now take the New supplied Bar End and remove the bolt. Pass the bolt through the hole in the end of the Handguard. You will see the Bar End has a slot cut in it which matches the width of the Handguard and holds it in place.
- 4, Insert the Bar End and Handguard into the handlebar, and tighten the bolt so it is a snug fit. Do not fully tighten now as you will need to adjust position later.
- 5, Now the handguard is held on at one end its time to secure the other end. This is done with the handlebar brace/support. Firstly, remove all 3 bolts from the support. With the clamping section in 2 halves wrap it around your handlebar in an under fashion rather than over. Put the 2 bolts back in and leave loose. Next take the third/last bolt and pass it through the handguard and into the hole on the brace/support.
- 6, Once all the fixings are in position you can position the handguard exactly where you want it and fully tighten all the fixings.
- 7, The handguards also come with an extra decorative section which can now be fitted using the self-tapping screws supplied.
- 8, Repeat the above steps for the left-hand handguard.
- 9, No go for a well-deserved ride.

Top Tips

- 1, On some occasions you may need to adjust the brake or clutch lever position or re-route cables along the handlebar to avoid clashing with the Handguard.
- 2, As mentioned above its best not to fully tighten any fixings until all of them are in place and the handguard is correctly positioned.
- 3, Remember you can always use the photos on the MPW website for reference with these instructions.