

Handguard Fitting Instructions (MPW-SVG-0353-03)

- 1, Open the packaging and separate evenly all the components into Left and Right piles.
- 2, Remove the bolt that holds the existing right-hand Bar-End into the handlebars and place the bar end to one side as you will not be re-using this again. Only do one side for now.
- 3, Now take the New supplied Bar End and remove the bolt. Pass the bolt through the hole in the end of the Handguard. You will see the Bar End has a slot cut in it which matches the width of the Handguard and holds it in place.
- 4, Insert the Bar End and Handguard into the handlebar, and tighten the bolt so it is a snug fit. Do not fully tighten now as you will need to adjust position later.
- 5, Now the handguard is held on at one end its time to secure the other end. This is done with the handlebar brace/support. Firstly, remove all 3 bolts from the support. With the clamping section in 2 halves wrap it around your handlebar in an under fashion rather than over. Put the 2 bolts back in and leave loose. Next take the third/last bolt and pass it through the handguard and into the hole on the brace/support.
- 6, Once all the fixings are in position you can position the handguard exactly where you want it and fully tighten all the fixings.
- 7, The handguards also come with an extra decorative section which can now be fitted using the self-tapping screws supplied.
- 8, Repeat the above steps for the left-hand handguard.
- 9, The DRL indicators come supplied with tails. As connecting these requires connecting into the bikes existing loom, we advise you take the bike to an Auto Electrician to connect the lights.
- 10, No go for a well-deserved ride.

Top Tips

- 1, On some occasions you may need to adjust the brake or clutch lever position or re-route cables along the handlebar to avoid clashing with the Handguard.
- 2, As mentioned above its best not to fully tighten any fixings until all of them are in place and the handguard is correctly positioned.
- 3, Remember you can always use the photos on the MPW website for reference with these instructions.