

Chain Guard Fitting Instructions (MPW-SVG-0361)

1, Thoroughly clean the area around the end of the Swing Arm on the Chain side.

2, Now offer up the Guard underneath the Rear of the Swing Arm so the holes in the Guard line up with the mounting holes in the Swing Arm. Note the Guard should aim backwards with the mounting flange aiming towards you.

3, Next take the 2 supplied Bolts and Washers and lightly screw them through Guard and into the Swing Arm.

4, Once both Bolts are in and you are happy with the alignment you can fully tighten them.

Now go for a well-deserved test ride.