

Headlight Guard Fitting Instructions (MPW-SVG-0362-03)

1, Thoroughly clean the Headlight and area underneath prior to fitting.

2, Firstly offer the 2 Metal components up to each other. 1 is obviously the actual Headlight Guard, the other the Mounting Bracket. The Mount fastens on underneath the Headlight assembly so that the 2 Tabs face upwards allowing the Guard to bolt to it.

3, Now you know the orientation of the Mounting Bracket offer it up underneath the Headlight assembly in front of the Forks. You will see that the 4 holes in the Mounting Bracket identically match the 4 fixing points that are on the bikes Headlight support frame.

4, Undo the Bolts in the above-mentioned fixing points, offer up the Mounting Bracket and replace the Bolts. Do not fully tighten these yet.

5, Next take the Headlight Guard and the 2 supplied Nuts and Bolts and fasten the Guard to the Mount. Again, do not fully tighten yet, just enough to allow some movement.

6, With all the parts and fixings now in place you can line up the Guard to sit square and follow the contours of the Headlight. With this done you can now fully tighten ALL the fixings.

7, Lastly double check no cables or wires have been trapped or gripped by the above.

Now go for a well-deserved test ride.