

Radiator Guard Fitting Instructions (MPW-SVG-0365-02)

1, Thoroughly clean the Radiators and surrounding area prior to fitting.

2, Standing in front of the bike looking at the Radiators you will see the RH side unit has the Horn mounted slightly covering the Radiator and its lower inner fixing point. Loosen and place the Horn to one side for easier access.

3, Next offer up the RH Radiator Guard. You will see it has a half circular cut out in it which is clearance for the Horn assembly. With Guard held in place you will see the 3 Fixing points it will use. Loosen and remove All 3 Bolts.

4, Now use the replacement supplied Bolts and Washers to fasten the Guard to the 2 Inner fixing points. Do not fully tighten at this point. Then take the 3rd Bolt and Washer, pass it through the Guards Outer fixing hole, and then slide on one of the supplied Spacers before screwing the Bolt into the Inner edge of the Fairing. With All 3 Bolts now in you can fully tighten the Bolts and also re-fit the Horn.

5, Fitting the LH Guard is exactly the process as fitting the Right except the Horn does not need to be removed, so undo the 3 Fixings after offering up the Guard, Fit the 2 Inner Bolts and Washers first, then fit the Outer Bolt remembering to slide the Spacer on. Fully tighten all 3 Bolts once they are installed.

6, Lastly double check no cables or wires have been trapped or gripped by the above.

Now go for a well-deserved test ride.