

## Seat Cowl Fitting Guide (MPW-SVG-0367-02)

1, To begin the install remove the Pillion Seat Cushion. This is held in place by 1 bolt which is accessed from underneath the Rear Fender. With the bolt removed the cushion when pulled backwards away from the bike will lift free. Store the Cushion and Bolt safely for future use.

2, Next you need to remove the Leather Strap/Grab Handle. To do this you remove the Front Seat Cushion. This is done by depressing the release catch at Rear of the Cushion which will allow the seat to slide backwards and up.

Now you need to unbolt the Frame Brace that is clamping down the Strap/Grab Handle to the Frame. Once you have done this and lifted free the Strap, replace the Frame Brace and fully tighten. Like the rear Seat Cushion store safely for future use.

3, You can now replace the Front Cushion. Offer the Cushion to the bike and place on the Frame Sliding it forwards until it locks back in position.

4, You can now attach the Cowl. To do this slide the 2 frontal protruding Tabs into the equally positioned slots under the rear of the Front Cushion. This is a resistance fit so a little pressure may be required whilst taking care not to brake anything.

5, With the Cowl now in position you can use the supplied Bolt fixings to fasten the rear of the Cowl back down to the bike, by doing the reverse of Step 1.

7, Now the Cowl is fully fitted you can access the interior storage area by pulling the top of the backrest/cushion forwards releasing it from the friction pin. You then simply lift the backrest up and clear. Notice the 2 Tabs at the bottom of the Backrest that locate in 2 slots in the Cowl.

8, Lastly double check everything is fitted correctly and seated properly.

That is, if the install is complete, and you should go for a well-deserved test ride.