

Side Stand Shoe Installation Guide (MPW-SVG-0936)

Before you begin, clean the side stand thoroughly. If you have a centre stand you should place the bike on it for this job. If you do not have a centre stand it might be advisable to have a second pair of hands to help balance the bike.

- 1, With the side stand down, offer the Shoe up to the side stands stock foot. You will now see the Shoe only fits in one orientation. Remember this.
- 2, Next loosen and remove the fixing bolts on the top face of the Shoe, so the Shoe can come apart.
- 3, Now place the bikes stock foot into the recess in the anodised part of the Shoe.
- 4, With the Shoe base positioned you now need to offer up the clamping top plate. Once in position start winding in the fixing bolts.
- 5, Once the bolts are in finger tight, its wise to tighten them gradually working round each bolt in turn. This way all the bolts will tighten easier, and the top plate will sit level.
- 6, Once all the bolts are fully tightened and the top plate is sitting flush with the bottom Shoe the install is complete.
- 7, You can now test the side stand with the Extension Shoe fitted.
- 8, Lastly go for a well-deserved test ride.