

Fuel Tank Guard Fitting Instructions (MPW-SVG-0945)

1, Thoroughly clean the area behind the Triple Clamp and in front of the Fuel Tank.

2, Now loosen and remove the Bolts that hold the front of the Fuel Tank to the Frame. Place the to one side as they will not be used again.

3, You can now offer the Guard into position. It will only fit in one orientation, ensuring the Countersunk holes are facing upwards ready to receive the Countersunk Bolts.

4, Now screw in the 2 supplied Countersunk Bolts through the Guard, the Tank and into the Frame and fully tighten.

Now go for a well-deserved test ride.