

Rear Brake Reservoir Guard Fitting Instructions (MPW-SVG-0955)

1, Thoroughly clean the area around and including the Rear Brake Master Cylinder/Reservoir.

2, Now offer up the Guard over the Reservoir so the Larger protruding flanged fixing hole lines up with the nearest Frame Bolt above the Reservoir, whilst lining up by eye the 2nd smaller fixing point on the Master Cylinder.

3, With the 2 fixing points now ascertained loosen and remove the existing Bolts in those locations, and place to one side. (Keep the larger one to be re-used).

4, Now pass the small supplied bolt through the Guard, then through the supplied Spacer, and offer it up to the Bike and loosely screw the Bolt in.

5, Next take the Large Bolt removed in Step 3 and insert through the Guard and screw it back into the Bikes Frame.

6, Once both Bolts are screwed in you can fully tighten to factory specifications.

7, Lastly check the action of the Rear Brake to ensure nothing has been disturbed.

Now go for a well-deserved test ride.