

Screen Installation Guide (MPW-SVG-0956)

1, The new Screen will be mounted to the bike between the Headlight and the handlebars so take some time before you begin to thoroughly clean this area.

2, Directly above the headlight is an Infill Panel held in with 4 Bolts. These are the Bolt locations that will be used to fasten the Screens Mounting Brackets.

3, The 2 Mounting Brackets can now be bolted to the above-mentioned Infill panel, making note of the following orientations.

A, line up the Bracket so the 2 fixing points match the bikes.

B, the 2 upswept arms of the bracket should spread outwards NOT inwards.

C, the taller upswept arms should be located at the upper location NOT lower.

4, Once you have both Brackets loosely fitted offer up the Screen to check final alignment. If the Mounts need adjusting slightly to match the screen, make those adjustments now and then fully tighten the Bolts.

5, With the Brackets now fitted insert the 4 expanding rubber shrouded Nuts into the 4 fixing points of the 2 Brackets from above. These will act as a cushion for the screen, and expand on the rear to keep the screen locked in position.

6, Lastly offer the Screen up to the Brackets and insert the 4 supplied Bolts, once all 4 are in you can fully tighten the Bolts taking care not to over tighten them and damage the Screen.

7, Lastly take your bike for a much-deserved test ride.