

Indicators Fitting Guide (MPW-SVG-0961)

1, As the indicators are a direct OEM replacement the installation involves no adaption or adaption to the looms.

2, Firstly remove any panels required to access the 2 connectors. Disconnect the connectors at this point too and unclip any retainers that may be holding the indicator cables in place.

3, Now looking at the original fitted indicators you will see 2 screws. 1 large near the base, and 1 small near the lens. Ignore the small screw and undo and remove the Large Screw.

4, With the large screw removed you will be able to pull the plastic part of the indicator away from the rubber base. Then once free guide the cable with connector through the mounting bracket and rubber base. Then place the old indicators to one side.

5, Next offer up the new indicator and feed the connector and cable through access hole, then locate the indicator onto the rubber mount and screw the screw back in and fully tighten.

7, You can now dress the new cable into the bike the same as the original was and plug the 2 connectors back together.

7, Once you have completed the fitting you can replace any panels removed in Step 2.

8, Lastly turn on the electrics and test the indicators are functioning properly and are in the correct orientation.

That is, it the install is complete, and you should go for a well-deserved test ride.